MRo/APn

INSTRUCTION WORK WITH HIGH-PRESSURE JETS 25-200 BAR

For further information see "HMSS-348 Arbete med högtrycksstråle 25-200 bar".

- 1. Eye protection and foot and leg protection must be used.
- 2. Do not hold hands or other parts of the body in front of the nozzles.
- 3. Regulations banning minors from using high pressure equipment can be found in AFS 1990:19.
- 4. If there is leakage from the connections or couplings between hoses, the high pressure jet must not be used. Remedial action must also be carried out immediately on small leaks.
- 5. It is advisable to try the reaction force and the size of the change in the reaction force before starting work.
- 6. Ensure that electrical cables are intact and positioned so that they are not exposed to water, and that the high-pressure unit is not exposed to spray from the nozzle.
- 7. Personnel working with water jet pressures exceeding 200 bar must have undergone specialist training.